

Cuisinart®

INSTRUCTION BOOKLET

Recipe
Booklet
Reverse Side



Cook Central™ 4-in-1 Multicooker

MSC-800 Series

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be followed:

1. **READ ALL INSTRUCTIONS.**
2. Do not touch hot surfaces; use handles. Always use oven mitts when handling hot material.
3. To protect against risk of electrical shock, do not immerse the multicooker housing in water or any other liquid. If housing falls into liquid, unplug the cord from outlet immediately. **DO NOT reach into the liquid.**
4. To avoid possible accidental injury, close supervision is necessary when any appliance is used by or near children.
5. **Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.**
6. **Do not operate any appliance with a damaged cord or plug or after the appliance has malfunctioned or has been dropped or damaged in any way or is not operating properly. Return the appliance to the Customer Service Center (see Warranty for details) for examination, repair or mechanical or electrical adjustment.**
7. **The use of attachments not recommended by Cuisinart may cause fire, electrical shock, or risk of injury.**
8. **Do not use outdoors or anywhere the cord or unit housing might come into contact with water while in use.**
9. **Do not use the multicooker for anything other than its intended use.**
10. **This unit is not a deep fryer.**
11. To avoid the possibility of the multicooker being accidentally pulled off work area, which could result in damage to the cooker or personal injury, do not let cord hang over edge of table or counter.
12. To avoid damage to cord and possible fire or electrocution hazard, do not let cord contact hot surfaces, including a stove.
13. Extreme caution must be used when moving the multicooker containing hot oil or other hot liquids.
14. Do not place on or near a hot gas or electric burner, or in a heated oven.
15. Do not operate multicooker in water or under running water.

16. Avoid sudden temperature changes, such as adding refrigerated foods to a heated pot.
17. **CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, COOK ONLY IN THE POT PROVIDED OR IN CONTAINERS PLACED ON THE COOKING RACK IN THE PROVIDED POT.**
18. **CAUTION:** A heated pot may damage countertops or tables. When removing the hot pot from the multicooker, **DO NOT** place it directly on any unprotected surface. Always set the hot pot on a trivet or a rack.
19. **To disconnect, turn any control to off, then remove plug from wall outlet.**
20. Do not operate your appliance in an appliance garage or under a wall cabinet. **When storing in an appliance garage, always unplug the unit from the electrical outlet.** Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.
21. **A short power-supply cord is used to reduce the risk resulting from it being grabbed by children, becoming entangled in, or tripping over a longer cord.**
22. Intended for countertop use only.
23. **WARNING:** Spilled food can cause serious burns. Keep appliance and cord away from children. Never drape cord over edge of counter, never use outlet below counter, and never use with an extension cord.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

NOTICE

This appliance has a polarized plug (one prong is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

CONTENTS

Important Safeguards.....	2
Features and Benefits	3
Operation	4
Programming	
Brown, Sauté, Sear	4
Slow Cook	4

Roast	5
Steam.....	5
Cleaning & Care	6
Tips & Hints	6
Cooking Guidelines	9
Troubleshooting	10
Warranty Information	12


FEATURES AND BENEFITS

- 1. Glass Lid with Handle**
Check the progress of a dish without releasing heat.
- 2. Reversible Steaming/Roasting Rack**
Elevates ingredients to steam or lifts ingredients off pan bottom to roast.
- 3. Cast Aluminum Nonstick Cooking Pot**
Spreads heat evenly to perfectly brown, sear and sauté ingredients right in unit. Extra-large 7-qt capacity.
- 4. Retractable Cord (not shown)**
For convenient, easy storage.
- 5. BPA Free (not shown)**
All parts that come into contact with food are BPA free.



GETTING TO KNOW YOUR CONTROL PANEL

- a. Cooking Function Buttons**
Use to select SLOW COOK, ROAST, BROWN/SAUTÉ or STEAM.
- b. Time Directionals**
Use to set cooking time. Press and hold to scroll quickly; press and release to advance more slowly.
- c. Temperature Directionals**
Use to set cooking temperatures. Press and hold to scroll quickly; press and release to advance more slowly.
- d. Start/Stop Button**
Starts and stops cooking function.
- e. Blue Backlit LCD Display**
Side-by-side display shows cooking time and temperature.



OPERATION

Cooking is simple with the Cook Central™ 4-in-1 Multicooker. Use the slow cooker as you would a normal slow cooker, the roaster as you would a normal oven and brown/sauté as you would a skillet.

1. Select your cooking function.
2. Set your desired cooking time and temperature.
3. Press START/STOP to begin cooking.
4. To turn off the heater at any time during cooking, press START/STOP.

NOTE: Always use pot holders during and after cooking, and always lift the lid away from you – the unit is hot.

CHANGING SETTINGS DURING COOKING

Switching functions during cooking is easy. Press the new cooking function button and the unit will adjust to the default settings for your selection. Set your desired time and temperature as needed.

You can adjust cooking time or temperature at any point with the Time/Temperature Directionals.

There is no need to press START/STOP to select new settings.

COOKING WITHOUT A TIMER

If you do not wish to program a time, the unit will cook at the selected temperature until you manually turn the heater off. The heater will turn off after the maximum allowable cooking time for the selected function has been reached.

NOTE: Do not leave the unit on 500°F for over 1 hour – prolonged heat at this high temperature can harm the nonstick coating or overheat the unit.

SLEEP MODE

The multicooker is equipped with a power-saving Sleep mode that will turn off the lights if there is no use. The unit will also enter this mode if you manually stop cooking. Press any button to “wake up” the unit and operate as normal.

PROGRAMMING

BROWN, SAUTÉ, SEAR

1. Press BROWN/SAUTÉ. A preset temperature of 350°F will flash, as this is the most commonly used Brown/Sauté temperature.
2. Press Temperature Directionals to select a different temperature (from 250°F to 500°F).
3. Press the START/STOP button to begin preheating. Selected temperature will flash during heatup.
4. When selected temperature is reached, two beeps will sound. Add ingredients to cooking pot—for best results, do not crowd pot.
5. Once cooking is complete, press START/STOP to stop cooking, or if you’ve browned ingredients as a first step in your recipe, switch to the next function in your recipe. There is no need to press START/STOP again, as the unit is already cooking.

NOTE: Though browning is usually a hands-on task, you can set a cooking time if you wish with the Time Directionals. If time is selected, countdown will start when selected temperature is reached. Unit will automatically shut off when countdown is complete.

SLOW COOK

1. Fill cooking pot with ingredients and cover with lid.
2. Press SLOW COOK. A preset temperature setting of Low will flash, as this is the most commonly used Slow Cook setting.
3. Press Temperature Directionals to select High, Low, Simmer or Warm, displayed along the bottom of the LCD.
4. Set desired cooking time (up to 24 hours) with Time Directionals.
5. Press the START/STOP button to begin cooking. Selected time and temperature setting (High, Low, Simmer or Warm) will be displayed.


NOTE: If you brown ingredients before switching to slow cooking, the unit is already on, so Step 5 is not necessary.

- When slow cooking on High, Low or Simmer, the unit will beep five times at the end of the cooking time and will automatically switch to the Keep Warm setting for 8 hours.
- When Keep Warm time elapses, one beep will sound and heater will turn off.
- To turn the heater off manually at any time, press the START/STOP button.

NOTE: The U.S. Department of Agriculture (USDA) recommends that when cooking in a slow cooker, food should reach 140°F within 3 hours.

ROAST

- Put cooking rack in pot in Roast position, as shown below. Place ingredients on rack and cover pot with lid for faster heatup.



- Press ROAST. A preset temperature of 350°F will flash, as this the most commonly used Roast temperature.
- Use Temperature Directionals to select a different temperature (from 250°F to 450°F).
- Set desired cooking time (up to 6 hours) with Time Directionals.
- Press the START/STOP button to begin preheating. Selected time and temperature will flash as unit heats up.


NOTE: If you brown ingredients before switching to roasting, the unit is already on, so Step 5 above is not necessary.

- When selected roasting temperature is reached, the unit will beep two times and the timer will begin counting down cooking time.
- When cooking time has elapsed, the unit will beep five times and the heater will automatically turn off.

- Carefully remove food from pot with spoon, fork or tongs. **Do not use rack as handles; they will be hot.**
- To turn the heater off manually at any time, press the START/STOP button.

STEAM

- Place about 1 quart (4 cups) of water or other liquid in cooking pot and place cooking rack in steam position, as shown below; cover with lid. For best results, do not add ingredients to pot until steaming temperature is reached (preheating is complete).



- Press STEAM. Steaming temperature cannot be changed.
- Set desired cooking time (up to 1½ hours) by pressing Time Directionals.
- Press the START/STOP button to start preheating. Selected time and temperature will flash as unit heats up.
- When steaming temperature is reached, the unit will beep two times and the timer will begin counting down cooking time. With pot holders, carefully lift lid away from you and place food on rack, starting in the middle and working your way out. Be sure to cover pot with lid again.
- When cooking time is completed, the unit will beep five times and the heater will turn off automatically.
- Carefully remove food from pot with spoon, fork or tongs.
- To turn the heater off manually at any time, press the START/STOP button.

NOTE: The unit is equipped with a boil-dry protection. If all water has boiled out, the unit will shut off to avoid damaging the heater.

CLEANING & CARE

All removable parts are dishwasher safe.

1. Unplug unit and allow it to cool completely before cleaning.
2. Never immerse unit in water or other liquids.
3. To clean the housing and control panel, simply wipe with a clean damp cloth.
4. Wash cooking pot, lid and rack with warm soapy water and rinse thoroughly. Or, clean in the dishwasher.
5. Dry all parts after every use.
6. **Maintenance:** Any servicing should be performed by an authorized service representative.

NOTE: If food residue sticks to cooking pot surface, fill pot with warm soapy water and allow to soak before cleaning. If scouring is necessary, use a nonabrasive cleanser or liquid detergent with a nylon pad or brush.

TIPS & HINTS

- Heatup times may vary in different cooking modes, based on a number of factors. The selected temperature, the current temperature of the cooking pot, the contents of the pot, and other factors can all affect heatup time. For example, you may reach the set temperature in the Brown/Sauté mode, but require additional heatup time if you switch to the Roast mode, even though your temperature selection is the same. For an idea of how long it takes to reach a temperature in different modes, see below:
 - Brown/Saute (350°F, empty pot) - 5 min
 - Roast (400°F, with 4-lb roast) - 9½ min
 - Steam (1 quart of water) - 8½ min
- Always use nonstick utensils in your cooking pot. Metal utensils may damage the nonstick coating.

BROWN/SAUTÉ TIPS

- Use Brown/Sauté as you would a skillet or sauté pan on the stove – from quickly sautéed skillet dishes to the first step in many braised or slow-cooked dishes.
- Brown/Sauté also works well to brown foods on all sides before roasting.
- For even browning, it is important not to crowd the pan. Foods should be cooked in an even layer on the bottom of the pan, so it is good to cook foods in batches when necessary.
- Many recipes call for browning and sautéing foods before slow cooking or roasting. Some items produce more grease and fat than is desirable in the finished dish. To remove the excess grease, using pot holders, very carefully remove the cooking pot from the base and pour out the grease from the corner of the cooking pot. Return the cooking pot to the base and finish cooking the dish as desired.
- When browning meats, any brown bits that are left in the bottom of the pan can be used to flavor the dish. Simply add a small amount of liquid (like wine or broth) to the pan and scrape up the browned bits with a wooden spoon – leave in pot. Incorporate into the dish or sauce.
- Foods can be reheated with the Brown/Sauté function. Put precooked foods into the cooking pot. Set on Brown/Sauté at 350°F. Stir ingredients while heating so that all ingredients are warmed through. Once food is simmering, switch to Warm on the Slow Cook function for serving.

ROASTING TIPS

- For roasting, foods should first be placed on the roasting rack and then into the multicooker pot. The pot should then be covered during preheating and cooking.
- There are some recipes that do not require the use of the rack – some dishes benefit from direct heat.
- Be careful removing foods after roasting, as the sides of the pot can still be very hot. Allow foods like roasted meats to

rest for about 10 minutes for juices to distribute evenly. Remove foods from rack and arrange on a cutting board or platter for serving.

- Foods like meats and poultry benefit by browning first on all sides to caramelize the exterior and lock in flavors.
- For easy food release, spray roasting rack with nonstick cooking spray before roasting.
- Baked goods like cakes and breads can also be prepared using the Roast function. An 8-inch round or square pan or a loaf pan fits well on top of the roasting rack. For baking, the roasting temperature should be set the same as you would your oven.

SLOW COOKING TIPS

- Slow cooking is perfect for foods that require long, slow simmering, such as soups, stocks, stews, and dried beans.
- Slow cooking is ideal for tougher and less expensive cuts of meat like shoulder and pot roast.
- We encourage browning foods before slow cooking as it adds much depth and flavor to the finished dish. However, if time is short this step can be skipped and all ingredients can be added to your cooking pot to slow cook.
- When converting a traditional slow cook recipe for the multicooker that incorporates the Brown/Sauté or Roast function first the liquid amount will need to be increased. This is because the cooking pot will start at a higher temperature than it would in a traditional slow cooker. Every recipe is different and we've created our recommended recipes accordingly, but our approximate guideline is to double the liquid for a long braise and increase it by about 50% for a soup or stew. Also, set the slow cook timer to the lower end of the recommended time range.
- Ground meats should always be browned before slow cooking.
- Slow cook up to 24 hours, with an 8 hour Keep Warm. Certain foods benefit from a long, slow cook time on either Low or Simmer, but may be finished and

served much sooner. Some included recipes have a range of cooking times – adjust the recommended time to suit yours.

- For best cooking results, fill multicooker at least one-quarter full but not more than three-quarters full.
- To ensure that root vegetables such as carrots and potatoes are cooked through, they should be cut no larger than 1-inch pieces. This is most important for slow-cooked dishes under 6 hours.
- “Crisp-tender” vegetables should be added during the last 30 minutes of cooking time to prevent overcooking. Fresh herbs should be stirred into dishes immediately before serving.
- In general, cooking for 1 hour on High is the equivalent of cooking for 2 hours on Low.
- The Keep Warm function keeps foods at perfect serving temperature after they are finished cooking on the Slow Cook function.
- We do not recommend removing the lid when slow cooking as heat will escape, requiring extra cooking time. Each time the lid is removed, about 15 to 20 minutes of cooking time should be added.
- A fat mop can be used to remove separated fat from slow-cooked food by brushing it over the top. Alternatively, the food may be refrigerated and the congealed fat can then be lifted off and discarded before reheating and serving.
- Many slow-cooked foods such as stews benefit from cooling and refrigerating, then reheating – as the saying goes, stew or chili is always better the second day.
- A great way to reheat slow-cooked foods is to bring them to a simmer on the Brown/Sauté function at 350°F. Stir to ensure all ingredients are warmed through and then switch to Warm on the Slow Cook function for serving.
- If using frozen foods, thaw completely before slow cooking.
- Recipes can be assembled the night before cooking. Brown ingredients if

necessary and then combine with remaining ingredients in cooking pot. Cover and refrigerate. When ready to cook, place the cooking pot in the cold multicooker and add 30 minutes to your projected cooking time.

- To decrease the amount of fat in recipes, remove as much of the visible fat as possible from meats and poultry. Remove skin from poultry and drain any fat from browned meats.
- Dried beans should be soaked overnight, then brought to a boil, drained and rinsed before cooking. Do not add salt or any acid to beans when cooking, as it will prevent them from softening completely. Dried beans can be cooked ahead, drained and frozen. Thaw to add to your favorite recipes.

Adapt your own recipes to slow cook:

- For recipes that do not require Brown/Sauté or Roast function before slow cooking, reduce the cooking liquid by at least 50% (soups are the exception). Liquids do not evaporate as they do in traditional cooking, and most often you will end up with much more liquid than you began with.
- When converting a traditional slow cook recipe that incorporates the Brown/Sauté or Roast function first, the liquid amount will need to be increased. Every recipe is different. Our approximate guideline is to double the liquid for a long braise and increase it by about 50% for a soup or stew. Also, set the slow cook time to the lower end of the recommended time range.
- Certain cuts of meat are more appropriate for slow cooking. Lean cuts such as boneless, skinless chicken breast or pork tenderloin may seem dry if slow cooked. See our suggestions on page 9 for more information.
- Dairy products (milk, sour cream, some cheeses) will break down and curdle during slow cooking. Substitute canned evaporated milk, nonfat dry milk, or add dairy products during the last 30 minutes of cooking.

- When making soups, add solid ingredients to multicooker and then liquid to cover. If a thinner soup is desired, add more liquid to taste when finished.
- If your recipe calls for precooked pasta, UNDERCOOK it and add to the pot in the last 30 minutes of slow cooking. The same goes for rice. Add precooked rice in the last 30 minutes of cooking.

STEAMING TIPS:

- Steaming is one of the healthiest methods of cooking, as the smallest amount of nutrients are lost in the cooking process.
- To steam, fill the multicooker pot with 1 quart of water unless otherwise indicated.
- When adding heavier foods like corn on the cob to the steaming rack, place them on the middle of the rack and work your way to the edges.
- There are some instances when it is best to add ingredients to the rack before preheating, such as delicate food like dumplings or tamales.
- Always use caution when removing lid. It is best to remove the lid away from you.

COOKING GUIDELINES

Slow Cooking Modes

Three cooking modes, Simmer, Low and High, give you the opportunity to prepare a wider variety of dishes. You will usually want to use the Simmer or Low setting for recipes that cook longer. If you're starting a dish later in the day, select the High setting to ensure that your food is cooked, warm, and ready when you'd like to eat.

SETTING	GUIDELINES	RECIPES	TEMP	TIMER
High	This is the setting to use when you don't have time for a long, slow cook. It's also the setting to select when "baking" in your slow cooker.	Potatoes, casseroles, puddings, rolls	212°F (100°C)	Programmable up to 24 hours, then 8 hours (Warm)
Low	Low is the standard slow cooker temperature, and is ideal for foods that you start in the morning before work and enjoy at the end of your day.	Braised foods, roasts, stews, ribs, casseroles, shanks, chops, less tender cuts of meat, soups	200°F (93°C)	Programmable up to 24 hours, then 8 hours (Warm)
Simmer	The longer the cooking time, the more flavors blend together and intensify.	Soups, stews, stocks	185°F (85°C)	Programmable up to 24 hours, then 8 hours (Warm)
Warm	Do not use this setting to cook food or as a cooking function. This setting is intended only for use with preheated foods.	----	165°F (74°C)	Defaults up to 8 hours. Or programmable up to 24 hours

Suggested Cuts of Meat for Slow Cooking

BEEF/VEAL	PORK	LAMB	POULTRY	GAME
Choose cuts that are full of flavor and benefit from braising to tenderize.	Less tender cuts work best. Tenderloin will become tough if slow cooked.	Choose flavorful cuts that benefit from braising to tenderize.	Best choice – dark meat – bone-in and skinless. Breast meat can be cooked in Slow Cooker, but will become dry in texture.	Game generally tends to be less tender, therefore it is perfect for the Slow Cooker.
Arm pot roast; beef brisket or corned beef brisket; beef short ribs; bottom round roast; chuck or rump roast; chuck shoulder steak; veal shanks	Boston butt roast; pork shoulder pieces; sausages; country style pork ribs (bone-in); pork shoulder or blade roast	Lamb shoulder; lamb stew meat; lamb shanks	Chicken or turkey legs and thighs	Venison roasts or stew meat, pheasant, duck thighs and legs

Steaming Chart

FOOD	AMOUNT	PREPARATION	COOKING TIME
Artichokes	6 individual	trimmed – see recipe page 26	40–50 minutes
Asparagus	1 pound medium	trimmed	4 minutes
Broccoli	1 bunch (about 16 to 20 oz.)	2-inch florets	6–7 minutes
Carrots, baby	1 pound	whole	8 minutes
Cauliflower	1 medium head (about 20 oz.)	2-inch florets	7–9 minutes
Corn	4 ears	husked	10–12 minutes
Green Beans	1 pound	trimmed	7 minutes
Peas, snow	1 pound	trimmed	4 minutes
Potatoes, new	1 pound	quartered/halved	12–15 minutes
Potatoes, yellow/gold	16–20 ounces	slices or ¾-inch pieces	10–12 minutes
Potatoes, sweet	16–20 ounces	slices or ¾-inch pieces	8–10 minutes
Squash, summer/zucchini	1 pound	½-inch slices	5 minutes
Chicken	1 pound (about 2 large breasts)	whole	12–15 minutes
Shrimp*	1 pound (large)	peeled & deveined	2–4 minutes
Fin Fish (salmon, swordfish, etc.)	1 pound	cut into portion sizes	8–12 minutes

*3 cups of water should be used here

TROUBLESHOOTING

Error Codes

- - - - - (flashing) indicates that the pot has been removed from the unit or is not seated properly. The heater will turn off temporarily if the pot is removed to avoid damage. Once the pot is returned, the unit should resume cooking.

Note: If the pot is out of place for over

15 minutes, you will need to restart the program.

Err indicates the unit has overheated. Wait for the unit to cool down and try again. If the problem persists contact Customer Service at 1-800-726-0190.

Troubleshooting Chart

Subject	Question	Answer/Solution
Power	Why won't my unit turn on?	Check to make sure your unit is plugged into a functional outlet.
		Contact Customer Service at 1-800-726-0190.
	Why is my unit turning itself off?	If no cooking function has been started, the cooker will enter sleep mode after 5 minutes of no use. All lights will turn off. Press any button to "wake up" the unit and operate as normal.
		It is possible the unit overheated. Wait for the unit to cool down and try again. If it does not turn back on, contact Customer Service at 1-800-726-0190.
		If all of your water has boiled out during steaming, the unit will shut off as a safety precaution. To continue steaming, add water to the pot and restart the program.
		If the pot is out of place for more than 15 minutes, when the pot is replaced, the unit will not resume cooking. You will need to restart the program.
		If changing functions when the unit is already cooking, you do not need to hit the START/STOP button again to select. Doing so will turn the unit off. Simply press your new function and select your desired settings; the unit will switch automatically.
		The heater will turn off automatically after the cooking time and/or Keep Warm time have elapsed. This is normal.
If you do not set a cooking time, the unit will cook for the maximum allowable cooking time before shutting off automatically. This is normal.		
Programming	Can I set a timer for the Brown/Sauté function?	Yes. Setting a timer for brown/sauté is an optional step. Simply set your timer using the Time Directionals as you would any other function.
	Can I change my cooking function, time or temperature when the unit is already cooking?	Yes. Simply use the cooking function, Time and Temperature Directionals, to change your programming. Note: The unit is already on, so you do not need to hit the START/STOP button again to select. Doing so will turn the unit off. Simply press your new function or desired settings; the unit will switch automatically and adjust accordingly.
Cooking	When should I brown my meat before slow cooking/roasting?	Browning meat before slow cooking and roasting is an optional step. It is beneficial, as it adds flavor and color, but the step can be omitted if time is short. Exception: ground meats.
	Which position should the rack be in for steaming/roasting?	The rack is intended for steaming in the "up" position. The rack is intended for roasting in the "down" position (see page 5).
	Can I use the cooking pot on the stove/in the oven?	The cooking pot was designed specifically for use in this multi-cooker. We do not suggest using it on the stove or in the oven.
	Why is there not enough liquid in my slow cooked dish?	Recipe ingredient amounts may vary if using multiple functions. See page 8 for details.
Cleaning	Can I put my unit in the dishwasher?	All removable parts are top-rack dishwasher safe.
		Do not immerse or put the base of the unit in the dishwasher. Clean the base and control panel with a clean damp cloth.
	The pot is nonstick – why is food sticking?	While the pot does have a nonstick coating, it is possible for food residue to burn onto the pot, making it difficult to remove.
Food residue is sticking to the cooking pot surface. How do I clean it without damaging it?	If food has burned on, fill pot with warm soapy water and allow to soak before cleaning. If scouring is necessary, use a non-abrasive cleanser or liquid detergent with a nylon pad or brush.	

WARRANTY

LIMITED THREE-YEAR WARRANTY

This warranty is available to consumers only. You are a consumer if you own a Cuisinart® Cook Central™ Multicooker that was purchased at retail for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners. We warrant that your Cuisinart® Cook Central™ Multicooker will be free of defects in materials and workmanship under normal home use for 3 years from the date of original purchase.

We recommend that you visit our website, www.cuisinart.com for a fast, efficient way to complete your product registration. However, product registration does not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this warranty will be the date of manufacture.

CALIFORNIA RESIDENTS ONLY

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (A) to the store where it was purchased or (B) to another retail store that sells Cuisinart products of the same type. The retail store shall then, according to its preference, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If either of the above two options does not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility, if service or repair can be economically accomplished. Cuisinart and not the consumer will be responsible for the reasonable cost of such service, repair, replacement, or refund for nonconforming products under warranty. California residents may also, according to their preference, return nonconforming products directly to Cuisinart for repair or, if necessary, replacement by calling our Consumer Service Center toll-free at 800-726-0190. Cuisinart will be responsible for the cost of the repair, replacement, and shipping and handling for such nonconforming products under warranty.

BEFORE RETURNING YOUR CUISINART PRODUCT

If your Cuisinart® Cook Central™ Multicooker should prove to be defective within the warranty period, we will repair or, if we think necessary, replace it. To obtain warranty service, please call our Consumer Service Center toll-free at 1-800-726-0190 or write to: Cuisinart, 7475 North Glen Harbor Blvd. Glendale, AZ 85307. To facilitate the speed and accuracy of your return, enclose \$10.00 for shipping and handling. (California residents need only supply a proof of purchase and should call 1-800-726-0190 for shipping instructions.) Be sure to include your return address, description of the product's defect, product serial number, and any other information pertinent to the return. Please pay by check or money order. **NOTE:** For added protection and secure handling of any Cuisinart product that is being returned, we recommend you use a traceable, insured delivery service. Cuisinart cannot be held responsible for in-transit damage or for packages that are not delivered to us. Lost and/or damaged products are not covered under warranty.

Your Cuisinart® Cook Central™ Multicooker has been manufactured to the strictest specifications and has been designed for use only in 120 volt outlets and only with authorized accessories and replacement parts. This warranty expressly excludes any defects or damages caused by attempted use of this unit with a converter, as well as use with accessories, replacement parts or repair service other than those authorized by Cuisinart. This warranty does not cover any damage caused by accident, misuse, shipment or other than ordinary household use. This warranty excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of these damages, so these exclusions may not apply to you. You may also have other rights, which vary from state to state.

Important: If the nonconforming product is to be serviced by someone other than Cuisinart's Authorized Service Center, please remind the service to call our Consumer Service Center at 1-800-726-0190 to ensure that the problem is properly diagnosed, the product is serviced with the correct parts, and to ensure that the product is still under warranty.

©2017 Cuisinart

150 Milford Road
East Windsor, NJ 08520

Printed in China

17CE028531

IB-11965A