



QUICK REFERENCE GUIDE

SETUP AND USE


- 1.** Fully immerse the charcoal water filter in cold tap water and soak for 15 minutes (see complete instructions on page 8 of your instruction booklet). Insert the filter into the water filter holder. Open the water reservoir and place filter holder into the unit.




- 2.** Pour desired amount of water into the water reservoir. A water level indicator is located on the side of the unit.




- 3.** Insert the permanent gold tone filter or paper filter into the filter basket holder. Using the scoop provided, add 1 scoop of ground coffee per cup - you can adjust the amount to taste. Close the lid.



- 4.** Check to make sure the filter basket is securely in place and lid is completely closed.



- 5.** To brew coffee, turn the Function Knob to the Brew position. Then press the On/Off button and release. The red ON indicator light will illuminate and brewing will begin.



IMPORTANT!

Do not throw away. Read before operating your new coffeemaker. Keep for further reference.


These helpful hints are intended to be a supplement to the instruction booklet. In order to ensure proper operation and optimum performance, please read the entire instruction booklet.

Please see reverse side for programming instructions.


QUICK REFERENCE GUIDE

PROGRAMMING


- 1. To set the time:** Turn the Function Knob to Clock. Press and hold the Hour or Minute button until the clock begins flashing. Hold down the Hour or Minute button to scroll through the numbers. When desired time approaches, release the button and press repeatedly to advance one digit at a time. To finish, wait for the numbers to stop flashing.




- 2. To program the Auto On:** Turn the Function Knob to PROG; the AUTO ON LED will flash. Set the time you want coffee to begin brewing (follow "set the time" instructions). Once complete, turn the Function knob to AUTO ON and press the On/Off button and release. The green indicator light will come on to remind you that the programming function is in use.




- 3.** At the programmed time, the red ON indicator light will come on, indicating that the brew cycle is starting.



- 4.** To start the brew cycle at the same time the next day, simply press the On/Off button and release. The green indicator light will illuminate.




- 5. To program the Auto Off:** Turn the Function Knob to Auto Off. Use the Hour and Minute buttons as in #1 (to set the time) to program your coffeemaker to shut off from 0 to 4 hours after brew cycle is finished.



Cuisinart®

12-Cup Classic Programmable Coffeemaker



Please see reverse side for setup and use instructions.