

Cuisinart® 9-Cup Food Processor

QUICK REFERENCE OPERATION GUIDE

- 1.** With the bowl on the base, use the handle to turn the work bowl clockwise to lock it onto the housing base.



- 2.** Carefully lift and remove the storage hub from the work bowl.



- 3. Using the universal chopping/mixing/dough blade:** Carefully place the blade onto the stem adapter. Holding top of stem adapter, lift and place over the work bowl accessory adapter. Blade should rest on the bottom of the work bowl.



- 4. Using the reversible slicing and shredding discs:** Insert the stem adapter without the universal blade. Choose the desired disc and carefully place disc over stem adapter, with the side being used facing up.



- 5.** Place the work bowl cover, with feed tube at the back of the work bowl, on the work bowl by latching the back on first and then pushing down on the front to lock into place. Align pushers with the feed tube opening on the work bowl cover and slide down to the bottom. Plug in the housing base. The machine is now ready for use.



- 6.** Add ingredients to the work bowl, either through the feed tube or directly into the bowl. Press the High or Low button and the motor will start. Press the Pulse/Off button when finished.

