

QUICK REFERENCE GUIDE

Cuisinart[®] baby[®]

Electric Steam Sterilizer

- 1.** Remove the measuring cup from the sterilizer lid.



- 2.** Lift off the sterilizer lid and set it aside.



- 3.** Fill the measuring cup with water to the fill line on the side of the measuring cup (100mL), then pour it into the sterilizing chamber.
NOTE: DO NOT EXCEED the recommended amount of water.



- 4.** Slide the stem through the lower tray to assemble, then place them in the sterilizing chamber.



- 5.** Place the bottles neck downward into the designated areas on the lower tray. **Note:** The tray hold up to 6 of the largest bottles available.



- 6.** Lift the upper tray by the center post in the middle of the tray and slide it over the stem attached to the lower tray in the steaming chamber.



STERILIZING CONTINUED

7. Loosely scatter the unassembled components on the upper tray. (It is important that all bottle parts are disassembled before adding them to the upper tray for proper sterilization).



8. Replace the measuring cup in the sterilizer lid and then place the lid on top of the sterilizing chamber.



9. Turn the dial to ON and the LED light will illuminate to indicate the sterilizing has begun. The unit and the LED light will shut off automatically once sterilizing is complete. Turn the dial to the OFF position.



10. Allow the sterilizer to cool for 10 minutes before opening, and wash your hands thoroughly before handling the sterilized items. **Note:** Sterilizer will be hot. Be careful when opening.



11. Carefully remove the sterile contents by lifting up from the stem sticking through the upper tray. Use caution when removing, as the items will be hot.

NOTE: The contents will remain sterile for up to 24 hours if the sterilizer is unopened.



12. To help prevent a buildup of calcium in the unit, drain and rinse the unit after each use. To empty the unit of excess water, wait until the unit has cooled, then tip the unit onto its side over the sink and any extra water will come out.



CLEANING

Decalcification

Sometimes mineral deposits form inside the sterilizing chamber that can cause damage to the machine. To avoid buildup of these minerals, the unit should be de-scaled once a month.

To descale, pour 1 cup of white (distilled) vinegar into the sterilizing chamber. Let it stand for at least 2 hours and then empty. Rinse the unit with water after you empty the unit of the vinegar to ensure it is properly rinsed out. Repeat if necessary.

IMPORTANT

**Do not throw away. Read before operating your new Electric Steam Sterilizer
Keep for future reference.**

These helpful hints are intended to be a supplement to the Instruction Booklet. In order to ensure safe operation and optimum performance, please read the entire Instruction Booklet.