

Cuisinart®

USE AND CARE

HOW SHOULD I CARE FOR MY NEW KNIVES?

Hand-wash cutlery for best results.

For optimal performance, periodically sharpen the edge of your knives using a knife sharpener. In between sharpening, you can use a honing rod to keep knife edges healthy and straight.

DOES YOUR SET INCLUDE BLADE GUARDS?



DOES YOUR SET INCLUDE A BLOCK?

To clean the block surface, wipe with a warm, wet cloth or sponge, and towel-dry immediately. Do not immerse in water.

DOES YOUR BLOCK INCLUDE A BUILT IN SHARPENER?

To Use Sharpener: Hold the side of the block with one hand and the knife handle with the other. While avoiding the sharpening V notch at the bottom of the sharpening slot, carefully insert the knife blade towards the top of the slot. After fully inserted, lower the blade into the sharpening V notch. While pushing the blade down into the sharpening notch using moderate pressure, pull the blade out from the base to tip while following the curve of the knife edge. For best results, only sharpen when removing the knife. Repeat the process as needed. Wipe blade clean with a soft cloth or paper towel before use.

DOES YOUR SET INCLUDE A CUTTING BOARD?

For cutting mats:

Dishwasher safe.

For poly cutting boards:

Dishwasher safe.

For wood cutting boards:

To clean the wood cutting board surface, wipe with a warm, wet cloth or sponge, and towel-dry immediately. Do not immerse in water.

LIFETIME WARRANTY (U.S. AND CANADA ONLY)

This warranty is available to consumers who purchase directly from Cuisinart or an authorized Cuisinart reseller only. You are a consumer if you own Cuisinart® Cutlery that was purchased at retail for personal, family, or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners or consumers who purchase from unauthorized Cuisinart resellers. Your Cuisinart® Cutlery is warranted to be free of defects in material and workmanship under normal home use from the date of original purchase throughout the original purchaser's lifetime.

HASSLE-FREE REPLACEMENT WARRANTY

Your ultimate satisfaction in Cuisinart products is our goal, so if your Cuisinart® Cutlery should fail within the generous warranty period, we will repair it or, if necessary, replace it at no cost to you. To obtain a return shipping label, email us at <https://www.cuisinart.com/customer-care/product-assistance/product-inquiry/>. Or call our Consumer Service Center toll-free at **1-800-726-0190** to speak with a representative.

This warranty excludes damage caused by accident, misuse, or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discoloration, or other damage to external or internal surfaces that does not impair the functional utility of the cutlery.

This warranty also expressly excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the foregoing limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

CALIFORNIA RESIDENTS ONLY

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (a) to the store where it was purchased or (b) to another retail store that sells Cuisinart® products of the same type. The retail store shall then, according to its preference, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If the above two options do not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility if service or repair can be economically accomplished. Cuisinart, and not the consumer, will be responsible for the reasonable cost of such service, repair, replacement, or refund for nonconforming products under warranty.

California residents may also, according to their preference, return nonconforming products directly to Cuisinart for repair or, if necessary, replacement by calling our Consumer Service Center toll-free at **1-800-726-0190**. To obtain a return shipping label, email us at <https://www.cuisinart.com/customer-care/product-assistance/product-inquiry/>. Cuisinart will be responsible for the cost of the repair, replacement, and shipping and handling for such nonconforming products under warranty.