

The Most Trusted Name in the Kitchen®

Cuisinart®

MINI FOOD PROCESSOR



Instruction and Recipe Booklet

CTG-00-PCH

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

CONTENTS

Important Safeguards and Instructions	3
Helpful Hints	4
Use and Care	4
Quick Start Guide.	5
Warranty	6
Recipes	7
Tomato Salsa	7
Guacamole	8
Sweet Crumb Topping	9
Product Registration	10
Notes	14

IMPORTANT SAFEGUARDS
SAVE AND READ THESE
INSTRUCTIONS
CAUTION: THE CUTTING BLADE
HAS VERY SHARP EDGES.

Basic safety precautions should always be taken, including the following:

1. **READ ALL INSTRUCTIONS, including these important safeguards.**
2. Close supervision is necessary when this mini food processor is used by or near children or individuals with certain disabilities.
3. Keep hands and utensils away from moving blade while processing, to prevent the risk of severe injury to persons or the chopper.
4. Blades are extremely sharp. Handle carefully when removing or cleaning. Always allow blades to stop moving before removing lid.
5. Be certain lid is securely locked in place before using. Do not attempt to remove lid until blades have stopped rotating.
6. Before using, check work bowl for presence of foreign objects.

FOR HOUSEHOLD USE ONLY

HELPFUL HINTS

- Maximum capacity—do not fill more than $\frac{2}{3}$ full for best results.
- When chopping nuts, do not use more than 1 cup.
- It is not recommended to chop very hard nuts (like almonds) or chocolate with this tool.
- When chopping garlic, use a minimum of 2 cloves, maximum of 12 cloves.
- For best results, be sure that all food is cut into the same size, no larger than 1 inch.
- Steady pulls work best to ensure the most even chop. Do not pull cord too fast.
- If food gets stuck in the top of the blade hub, use a toothpick or similar tool to clean out and flush well with water before washing.
- When chopping herbs, be sure that the bowl and blade are completely dry.
- On occasion, resistance may be felt when pulling. If this happens, food may be lodged between the blade and wall of the chopping cup. Stop, carefully remove piece of food and continue chopping.

USE AND CARE

- Container is top-rack dishwasher safe.
- Hand-wash lid and blades.

QUICK START GUIDE

1. Make sure blade tower is positioned securely on the center point in container.
2. Add ingredients to container.



3. Put lid onto container and turn to lock in place.
4. Place on a solid, flat surface and hold chopper firmly. Pull cord until food is chopped to desired consistency.



WARRANTY

LIFETIME WARRANTY (U.S. and Canada ONLY)

Cuisinart® Tools & Gadgets are warranted to be free of defects in material and workmanship under normal home use from the date of original purchase throughout the original purchaser's lifetime. If your tool/gadget should prove to be defective within your lifetime, we will repair it (or, if we think it necessary, replace it) without charge to you, except for shipping and handling. To obtain warranty service, please call our Consumer Service Center toll-free at 1-800-726-0190, or write to Consumer Service Center, Cuisinart, 150 Milford Road, East Windsor, NJ 08520. To facilitate the speed and accuracy of your return, please enclose \$4.00 for shipping and handling of the product. Be sure to include a return address, description of the product problem, phone number, and any other information pertinent to the product's return. Please pay by check or money order made payable to Cuisinart. This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discoloration or other damage to external or internal surfaces that does not impair the functional utility of the tool/gadget. This warranty also expressly excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the foregoing limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

CALIFORNIA RESIDENTS ONLY

California residents should call 1-800-726-0190 for shipping instructions. Cuisinart will be responsible for the cost of the repair, replacement, and shipping and handling of such nonconforming products under warranty.

RECIPES

Tomato Salsa

Makes about 1 cup

- 2** **tablespoons fresh cilantro, stems discarded**
- 1/4** **large onion, cut into 1-inch pieces**
- 1** **small garlic clove, peeled**
- 1/2** **jalapeño pepper, seeded and cut into 1-inch pieces**
- 1/2** **teaspoon kosher salt**
- 1** **cup grape tomatoes**

1. Put all ingredients, except for the tomatoes, into the container. Cover and pull to chop, about 6 to 10 pulls.
2. Add the tomatoes and pull until finely chopped, about 8 to 10 pulls.
3. Taste and adjust seasoning accordingly.

Nutritional information per serving (1/4 cup):

*Calories 12 (6% from fat) • carb. 3g • pro. 1g • fat 0g • sat. fat 0g
chol. 0mg • sod. 288mg • calc. 8mg • fiber 1g*

Guacamole

Makes about 1 cup

- 1** small garlic clove, peeled
- ½** jalapeño, seeded and cut into 1-inch pieces
- 1** tablespoon fresh cilantro, stems discarded
- 1** large ripe avocado, pitted and cut into 2-inch pieces
- 2 to 3** teaspoons fresh lime juice
- ½** teaspoon kosher salt

1. Put the garlic, jalapeño and cilantro into the container. Cover and pull to chop, about 6 to 8 pulls.
2. Scrape down the sides of the bowl and add the remaining ingredients. Pull to chop to desired consistency, about 8 pulls for a chunky guacamole.
3. Taste and adjust seasoning as desired. Serve immediately.

Nutritional information per serving (¼ cup):

*Calories 59 (73% from fat) • carb. 4g • pro. 1g • fat 5g • sat. fat 1g
chol. 0mg • sod. 288mg • calc. 7mg • fiber 2g*

Sweet Crumb Topping

Makes about 1 cup

- ½ cup pecan halves**
- 2 tablespoons rolled oats**
- 1 tablespoon light brown sugar**
- 1 tablespoon unsalted butter, room temperature**
- ¼ teaspoon ground cinnamon**
- Pinch ground nutmeg**
- Pinch kosher salt**

1. Put all of the ingredients into the container. Pull to finely chop, about 12 to 15 pulls.
2. Use as a topping for oatmeal, or other hot cereal, or sprinkle on yogurt or even vanilla ice cream! It is very versatile.

Nutritional information per serving (¼ cup):

*Calories 66 (77% from fat) • carb. 3g • pro. 1g • fat 6g • sat. fat 1g
chol. 4mg • sod. 18mg • calc. 5mg • fiber 1g*


REGISTER YOUR PRODUCT NOW!

Complete the two easy steps to register your product and receive premium customer service, special offers and more!

STEP 1

TAKE A PHOTO

Take a photo of your Photoregister Code below including the points (⦿)



STEP 2

SEND IT IN



SMARTPHONE US/CANADA

Text photo to 71403

OR



EMAIL WORLDWIDE

cuisinart@photoregister.com

OR



ONLINE WORLDWIDE

register.cuisinart.com

Need help? Visit Photoregister.com/help or text HELP to 71403.

W-9/026-ESP-C


¡REGISTRA TU PRODUCTO AHORA!

¡Completa dos pasos sencillos para registrar el producto recibe servicio de alta calidad, ofertas especiales y mucho más!

PASO 1

SACA UNA FOTO

Saca una foto del código Photoregister™ debajo, incluyendo los puntos (⦿)



PASO 2

ENVÍALA



TELÉFONO MÓVIL EE. UU./CANADÁ

Envía la foto a 71403

0



CORREO ELECTRÓNICO DESDE CUALQUIER PARTE DEL MUNDO

cuisinart@photoregister.com

OR



EN LÍNEA DESDE CUALQUIER PARTE DEL MUNDO

register.cuisinart.com

¿Necesitas ayuda? Visita Photoregister.com/help o envía AYUDA a 71403.

W-9/026-ESP-C

The Most Trusted Name in the Kitchen®

Cuisinart®



Cuisinart offers an extensive assortment of top quality products to make life in the kitchen easier than ever. Try some of our other countertop appliances and cookware, and Savor the Good Life®.

www.cuisinart.com

©2016 Cuisinart
150 Milford Road, East Windsor, NJ 08520
Printed in China

16CT022641

IB-14538